



Male Approved Chocolate Chip Cookies

1 C shortening

1 C sugar

1/2 C packed light brown sugar

1 t vanilla

2 eggs

2 C flour

1 t baking soda

1 1/2 C chocolate chips

1/2 C chocolate chunks

Preheat oven to 350 degrees. Cream shortening, sugars, and vanilla until light and fluffy. Add eggs and beat well. Combine flour and baking soda; add to sugar mixture. Stir in chocolate. Use small scoop to drop onto cookie sheet sprayed with Pam. Bake for 12 min or until light brown. Cool before removing.